


**Auto Soap Dispenser, 2 Spout,
Controller and Tank Reservoir**



**Auto Soap Dispenser, 2 Spout,
Controller and Tank Reservoir**

Item	Part	Description
1	THP3337	Sensor
2	THP3338	Spout nozzle
3	THP3363	Soap Mixing Chamber
4	THP3339	Screw M3x4
5	THP3340	Rubber Gasket
6	THP5369	Washer
7	THP5370	Mounting Nut
8	THP3341	Clear soap hose (L=78-3/4", 2000mm)
9	THP3342	Blue air hose (L=66-15/16", 1700mm)
10	THP3343	Tank joint
11	THP3344	Soap and air pump
12	THP3391	Controller board
13	THP3346	Ground wire w/ screws
14	THP3347	Float switch
15	THP3348	Sensor sockets
16	THP3349	Float switch connector
17	THP3350	Soap tank bracket set
18	THP3351	Soap tank cap
19	THP3352	Soap Tank
20	THP3364	Cap
21	TLK03001G#CP	Spout**
22	TLK01102U	Controller
23	THP3140#CP	Escutcheon for 1-1/8"~1-1/2" (28~38mm) hole
24	THP3439	Hose Clamp
25	THP3374	Mount Bracket