


**Auto Soap Dispenser, 2 Spout,  
 Controller and Tank Reservoir  
 with Sub Tank**



\*\* Original packaging of 2 qty.

TLK03001G#CP  
TLK01106UA  
TLK01401U**Auto Soap Dispenser, 2 Spout,  
Controller and Tank Reservoir  
with Sub Tank**

<b>Item</b>	<b>Part</b>	<b>Description</b>
1	THP3337	Sensor
2	THP3338	Spout nozzle
3	THP3363	Soap Mixing Chamber
4	THP3339	Screw M3x4
5	THP3340	Rubber Gasket
6	THP5369	Washer
7	THP5370	Mounting Nut
8	THP3341	Clear soap hose (L=78-3/4", 2000mm)
9	THP3342	Blue air hose (L=66-15/16", 1700mm)
10	THP3343	Tank joint
11	THP3344	Soap and air pump
12	THP3391	Controller board
13	THP3346	Ground wire w/ screws
14	THP3347	Float switch
15	THP3348	Sensor sockets
16	THP3349	Float switch connector
17	THP3350	Soap tank bracket set
18	THP3353	Air deflation hose set
19	THP3354	Soap Tank
20	THP3355	Coupling cap
21	THP3364	Cap
22	TLK03001G#CP	Spout**
23	TLK01106UA	Controller
24	THP3140#CP	Escutcheon for 1-1/8"~1-1/2" (28~38mm) hole
25	TLK01401U	Sub Tank
26	THP3369	Y-Shaped Nipple
27	THP3370	Hose Clamp
28	THP3371	Connecting Tube, 16.4' (5 m)
29	THP3372	Cap, Sub Tank
30	THP3373	Strainer, Sub Tank
31	THP3439	Hose Clamp
32	THP3374	Mount Bracket